

300M无线扩展器



2.打开手机搜索WIFI 设置界面，搜索并连接WIFI，WIFI 名称默认为：EDUP-XXXX格式（XXXX为随机码）。



1

EDUP_4455 < > 登录 取消



2

3

capive.apple.com
EDUP-4455

登录

取消



设置WiFi放大器

对您家的无线网络进行信号扩展，穿墙扛扛

选择要放大的无线信号或手动添加网络

无线网络名称：EDUP

▼

无线密码：12x3c5d

扩展一个无线名称为“XXX-Plus”的无线网络

说明：勾选后扩展的无线名称是XXX-Plus；若不勾选，扩展的无线名称是默认EDUP_4455。

下一步

4

5

设置

Wi-Fi

Wi-Fi

EDUP-Plus

选取网络...

EDUP

EDUP_5G

EDUP_5G_6F5F

HU-yamaxun_5G

6

1.如何恢复出厂设置?

答:在无线放大器设备通电的状态下,使用尖状物体(如回形针、牙签等)按压RST按钮,当看到设备灯熄灭表示恢复成功。

2.设备指示灯状态描述？

没有指示灯亮：未扩展WiFi或者未扩展成功
蓝灯长亮：扩展WiFi成功，信号很好
蓝灯闪烁：扩展WiFi成功，信号差
红灯闪烁：WPS功能尝试连接中

3.无法打开设置界面怎么办？

答：先确认您的手机连接的是您购买的本产品的WIFI信号，打开手机浏览器输入默认网关：192.168.20.1,可进入到设置界面。



7

300M WiFi Signal Repeater



2. Open the WIFI setting of your phone to search and connect WIFI, The default WIFI name is EDUP-XXXX format (XXXX is random code).



①

2

192.168.20.1

WiFi Extender Settings

Extend your WiFi signal

Choose your WiFi name

選擇網絡

📶

EDUP

📶

RT2802

📶

yangyamaun2G

📶

ETH ID:ueah9J AR5EY7

📶

Manually input the WiFi name

—

Note: Please select the network you want to extend.
If you don't find it, please refresh and try again.

Refresh

3

192.168.20.1

WiFi Extender Settings

Extend your WiFi signal

Choose your WiFi name

WiFi name :

EDUP

Password :

12x3c4v


✓ The Extend WiFi name is: EDUP-Plus.
Note: Tick the box, then a new WiFi name EDUP-Plus will be created. If not extended WiFi name will keep the same EDUP.

NEXT

4

192.168.20.1

Settings finished!



Original WiFi name: **EDUP**


New WiFi name: **EDUP-Plus**

WiFi password: **1z2x3c4v**

you want to config the wifi repeater again, please press
reset button on device to make factory default first.

Finish Settings

5



Tips:

Settings finished, please check the extender status of blue indicator lights.

Keeps on: Extended successful in appropriate distance.

Flashing: Extended successful but distance too far, suggest shortening the distance.

Put out: Extended failure, wrong password or distance too far.

6

1. How to restore factory settings?
Answer: When the wireless repeater device is powered on, press the RST button with a pointed object (such as a clip, a toothpick, etc.), and when the device light is turned off, it restore successfully.
2. Device indicator light status description?
Without indicator light turning on: didn't repeat WIFI or didn't repeat successfully.
Blue light is always turning on: expand WIFI successfully, the signal is very good.
3. What to do when can't open the settings interface?
Answer: First confirm that your phone is connected to the WIFI signal of this device, open the phone browser and enter the default gateway: 192.168.20.1, then you can enter the setting interface.



•